









**RECOMMENDED PRODUCTS FOR LIQUOR INDUSTRY**

	<b>NATURE</b>	<b>APPLICATION</b>	<b>PLACE OF APPLICATION</b>
<b>CPQ topfoam plus</b>	ALKALINE (Cleaning of organic remains)	Projection of foam	Simultaneous cleaning and disinfecting surfaces with foam debris syrups, etc.
<b>CPQ topfoam acid</b>	ACID (Remains of lime)	Projection of foam	Walls – floors - stainless steel tanks and pipes.
<b>CPQ ideal 500/r</b>	ACID (Lime descaler)	Spray or flood	Deposits, structures, machinery and stainless steel pipes.
<b>CPQ cintex fv</b>	CHAIN LUBE (Lubricante ligeramente alcalino)	Manual or automatic	Lubrication bottle conveyors to improve their glide.
<b>CPQ plus especial</b>	ALKALINE (Alkaline liquid detergent)	Manual or automatic	Alkaline liquid detergent for cleaning indoor circuit, deposits in the food industry.
<b>CPQ dinfex fg</b>	DESINFECTANT (Disinfectant cold immediate action)	Manual or automatic	Disinfection filling inside and outside, tanks, circuits, etc.



**PRODUCT APPLICATION FOR LIQUOR INDUSTRY**








CLEANING:	APPLICATION	SECURITY	FREQUENCY	DOSE AND TEMPERATURE. °C	MINIMUM CONTACT TIME.
PACKAGING AND PRODUCTION ROOM (CPQ topfoam plus)		 	DAILY	4%	20 minutes
				Room temperature	Rinse
PACKAGING AND PRODUCTION ROOM (CPQ topfoam acid)		 	MONDAY, WEDNESDAY, FRIDAY	4%	20 minutes
				Room temperature	Enjuague

Comment: The application of **CPQ topfoam** product , will be uniformly and always from top to bottom, left to right in the case of the floors to throw the foam in the same place and overloading thus preventing it from sliding too fast and therefore not achieve adequate cleaning.



**LOMISA Distribuciones y Proyectos, S.L.**  
 C/ Punta Umbría, 26  
 28939 – Arroyomolinos (Madrid)  
 Telf. 91 734 20 58  
 Fax. 91 790 37 34  
 Email: lomisa@lomisa.com

## PRODUCT APPLICATION FOR LIQUOR INDUSTRY

APPLICATION:	APPLICATION	SECURITY	FREQUENCY	DOSE AND TEMPERATURE, C°	APPLICATION TIME
CONVEYOR TABLES (CPQ cintex fv)			DAILY	4%	30 seconds / start 30 seconds / stop
LIMPIEZA DE LLENADORAS (CPQ topfoam plus)		 	DAILY	4%	20 minutes
(CPQ topfoam acid) (CPQ ideal 500/r)			WEEKLY	4%	Rinse
CIRCUITS AND DEPOSITS (CPQ plus especial) (CPQ dinfex fg)		 	ACCORDING TO PROTOCOLS	4% 0,5%	20 minutes
				Room temperature	Rinse